



- 8 3/4" DAUB OF DETAIL SEALANT PW OR LM-95 TOOLED ONTO SURROUNDING FABRICS
- 4 PREPARE & CLEAN THE EXPOSED BOOT COMPOUND AND UNDERSLAB FABRIC 6" TO EACH SIDE OF THE END LAP
- 5 APPLY 650 LT LIQUID ADHESIVE OR CALIFORNIA SEALANT TO THE CLEANED AREA AT THE RATE OF 50-75 SF / GAL
- 6 COVER THE SELECTED ADHESIVE OR SEALANT WITH FABRIC TAPE
- 7 ROLL THE FABRIC TAPE WITH A HANDHELD HARD SURFACE ROLLER

US21

UNDERSLAB MEMBRANE PIT SIDEWALL TRANSITION AT TOP OF WALL

©POLYGUARD PRODUCTS, INC.

Polyguard Products, Inc.
 P.O. Box 755 - Ennis, TX 75119
 Phone: 214-515-5000 Fax: 972-875-9425
 Web Site - www.polyguard.com

The information provided is based on data and knowledge considered to be true and accurate and is offered for the users' consideration, investigation and verification, but we do not warrant the results to be obtained. Please read all data sheets, statements, recommendations or suggestions in conjunction with our conditions of sale, which apply to all goods supplied by us.

NOT TO SCALE
EFFECTIVE DATE: 10-01-2014
SUPERCEDES: 03-18-2014